


## Turn Signal Testing



### Wiring:



●	Black	Ground – Horn
●	Light Green	Left Front Turn Signal
●	Tan	Right Front Turn Signal
●	Pink	To Emergency Flasher < via Battery Power
●	Red	To Emergency Flasher < via Switched Power
●	Dark Green	Left Rear Turn Signal
●	Brown	Right Rear Turn Signal
●	White	Brake Light Switch < Battery On

### Brake Light Switch On Connections:



●	Black	Ground – Horn
●	Light Green	Left Front Turn Signal
●	Tan	Right Front Turn Signal
●	Pink	To Emergency Flasher < via Battery Power
●	Red	To Emergency Flasher < via Switched Power
B	Dark Green	Left Rear Turn Signal
B	Brown	Right Rear Turn Signal
B	White	Brake Light Switch < Battery On

### Left Turn Signal On Connections:



●	Black	Ground – Horn
T	Light Green	Left Front Turn Signal
●	Tan	Right Front Turn Signal
●	Pink	To Emergency Flasher < via Battery Power
T	Red	To Emergency Flasher < via Switched Power
T	Dark Green	Left Rear Turn Signal
●	Brown	Right Rear Turn Signal
●	White	Brake Light Switch < Battery On

## Turn Signal Testing

### Left Turn Signal AND Brake Light On Connections:

●	Black	Ground – Horn
T	Light Green	Left Front Turn Signal
●	Tan	Right Front Turn Signal
●	Pink	To Emergency Flasher < via Battery Power
T	Red	To Emergency Flasher < via Switched Power
T	Dark Green	Left Rear Turn Signal
B	Brown	Right Rear Turn Signal
B	White	Brake Light Switch < Battery On

### Right Turn Signal On Connections:

●	Black	Ground – Horn
●	Light Green	Left Front Turn Signal
T	Tan	Right Front Turn Signal
●	Pink	To Emergency Flasher < via Battery Power
T	Red	To Emergency Flasher < via Switched Power
●	Dark Green	Left Rear Turn Signal
T	Brown	Right Rear Turn Signal
●	White	Brake Light Switch < Battery On

### Emergency Flasher On Connections:

●	Black	Ground – Horn
E	Light Green	Left Front Turn Signal
E	Tan	Right Front Turn Signal
E	Pink	To Emergency Flasher < via Battery Power
●	Red	To Emergency Flasher < via Switched Power
E	Dark Green	Left Rear Turn Signal
E	Brown	Right Rear Turn Signal
●	White	Brake Light Switch < Battery On

### Emergency Flasher On AND Brake Light On Connections:

Brake Lights Switch disabled when Emergency Flasher is on.