

r:::aaZ::: sika

Z! c:127: u=.

1 r 6 H a

the door bolts will give you your in and out, but can give you a small amount of up and down. the bolts on the body give you high and low, and a small amount of up and down. for your drop, I would loosen the bottom body bolts(one you have to access from behind) loosen up the upper hinge, all but one bolt the one at the top. just crack that one to act as a pivot. pull it up and tighten up an upper and lower bolt and check. it usually takes a few times, to go down reverse the order. In and out same theory. to bring the bottom out loosen all the bottom bolts, the top bolts all but one, crack that last one and twist. go a little, check it and if need be repeat. you can remove the striker Fr:!!=-:-: | ■ |

I\

